

# Quick Start Guide



Platinum Wireless Headset



For more information, visit [playstation.com/helpme](http://playstation.com/helpme). The example shown is not representative of an actual screen. "PS", "PlayStation" and "DUALSHOCK" are registered trademarks or trademarks of Sony Interactive Entertainment Inc. "Sony Entertainment Network" is a registered trademark of Sony Corporation. Windows is either a registered trademark or trademark of Microsoft Corporation in the United States and/or other countries. Mac is a trademark of Apple Inc., registered in the U.S. and other countries.

# Let's get started

**IMPORTANT:** Before using this product, read the safety precautions in the Safety and Support Guide.

You can also use your headset with a PC, Mac or portable media player. For details, visit: [us.playstation.com/support/wirelessstereoheadset](http://us.playstation.com/support/wirelessstereoheadset).

## 1. Turn on your PS4™ system



Press the power button.

## 2. Charge your headset



With your PS4™ system on\*, connect your headset using the supplied USB cable. Your headset might need up to 3.5 hours to charge fully.

\*You can also charge your headset when your PS4™ system is in rest mode.

## 3. Insert the wireless adaptor



Use one of the USB ports on your PS4™ system.

## 4. Turn on your headset



Slide the power/audio mode switch to position "1" or "2".

1. Press and hold the PS button on your DUALSHOCK®4 wireless controller.
2. Select [Sound/Devices] > [Output to Headphones].
3. Select [All Audio].



5. Download and install the Headset Companion app from PlayStation®Store\*.
6. Open the Headset Companion app and update your headset.

Select one of the preset modes, which have been specially designed to deliver an optimal audio experience. You can also create your own audio mode.

## Enhanced 7.1 Virtual Surround Sound:

Experience rich, highly positional virtual surround sound powered by a new 3D audio technology from Playstation®.

## 3D Audio:

In supported games for the PS4™ system, 3D audio delivers an amazingly rich audio experience via object-based surround sound emanating from all directions, including above and below you, across 100 virtual speakers.

\* Sony Entertainment Network account and Internet service required.

# Headset anatomy



## SOUND/CHAT buttons

Adjust the chat voice volume in relation to the game sound.

## Status indicator

## Power/audio mode switch

Sets the audio mode or turns off the headset.

- OFF - turns off the headset
- 1 - standard mode
- 2 - bass boost mode

Both audio modes are customizable and can be replaced with other modes from the Headset Companion app.

## Rear

## VSS/3D AUDIO switch

VSS/3D AUDIO switch controls the audio format output desired by the player.

OFF - standard stereo output

ON - enhanced 7.1 virtual surround sound (VSS) for stereo/5.1/7.1 content or 3D audio for 3D audio content

## VOLUME + / - buttons

## MUTE button / Sidetone

The MUTE button controls the microphone and the sidetone feature. Sidetone allows you to hear your own voice from the headset.

When MUTE is on, the sidetone feature is turned off.

- Short press to mute or unmute the microphone.
- Long press to choose the sidetone volume (low, high, off).

**One beep** - low volume

**Two short beeps** - high volume

**One low beep** - sidetone off

## Bottom

## USB port

Connect a micro-USB cable to your PS4™ system or another compatible USB device to charge your headset.

## Microphone (integrated)

## Audio input jack

Use the supplied audio cable to connect your headset to mobile devices.

For more instructions about the use of this product (including the Headset Companion app), visit [us.playstation.com/support/wirelessstereoheadset](http://us.playstation.com/support/wirelessstereoheadset).

# Guide de démarrage rapide



Casque-micro sans fil platine



Pour de plus amples renseignements, visitez [playstation.com/helpme](http://playstation.com/helpme). L'exemple utilisé n'est pas représentatif d'un écran réel. "PS", "PlayStation" et "DUALSHOCK" sont des marques déposées ou des marques commerciales de Sony Interactive Entertainment Inc. "Sony Entertainment Network" est une marque déposée de Sony Corporation. Windows est une marque déposée ou une marque commerciale de Microsoft Corporation aux États-Unis et/ou dans d'autres pays. Mac est une marque commerciale d'Apple Inc., déposée aux États-Unis et dans d'autres pays.

## Pour commencer

**IMPORTANT** : Avant d'utiliser ce produit, veuillez lire les consignes de sécurité dans le Guide de sécurité et de support technique.

Vous pouvez également utiliser votre casque-micro avec un PC, un Mac ou un lecteur multimédia portable. Pour plus de détails, visitez [us.playstation.com/support/wirelessstereohdset](http://us.playstation.com/support/wirelessstereohdset).

### 1. Allumez votre PS4™



Appuyez sur l'interrupteur d'alimentation.

### 2. Rechargez le casque-micro



Avec votre PS4 allumée\*, connectez votre casque-micro à l'aide du câble USB fourni. Le casque-micro peut nécessiter jusqu'à 3,5 heures pour une recharge complète.

\*Vous pouvez également recharger votre casque-micro lorsque votre système PS4™ est en mode repos.

### 3. Insérez l'adaptateur sans fil



Utilisez un des ports USB de votre système PS4™.

### 4. Mettez le casque-micro sous tension



Glissez l'interrupteur d'alimentation/mode audio en position 1 ou 2.

1. Maintenez enfoncée la touche PS de votre manette de jeu DUALSHOCK®3 ou DUALSHOCK®4.
2. Sélectionnez [Son/Périphériques] > [Sortie vers le casque d'écoute].
3. Sélectionnez [Tout audio].



5. Téléchargez et installez l'application compagnon pour casque-micro à partir du PlayStation®Store\*.

6. Ouvrez l'application compagnon pour casque-micro et mettez à jour votre casque-micro.

Choisissez un des modes pré-réglés spécialement conçus pour offrir une expérience audio optimale. Vous pouvez également créer votre propre mode audio.

### Son ambiophonique virtuel 7.1 amélioré :

Profitez d'un son ambiophonique virtuel riche et hautement positionnel, optimisé par une nouvelle technologie audio 3D de PlayStation®.

### Audio 3D :

Dans les jeux pris en charge par le système PS4™, l'audio 3D offre une expérience sonore étonnamment riche grâce au son ambiophonique à base d'objets provenant de toutes les directions (y compris au-dessus et au-dessous de vous) à travers 100 haut-parleurs virtuels.

\* Avec un compte Sony Entertainment Network et une connexion Internet.

## Anatomie du casque-micro



Pour plus de détails concernant l'utilisation de ce produit (application compagnon du casque-micro comprise), visitez [us.playstation.com/support/wirelessstereohdset](http://us.playstation.com/support/wirelessstereohdset).