

### **CE (Europe) Declaration of Conformity**

The remote control is CE-certified.  
The declaration of conformity may be consulted at  
[www.swisscom.ch/tvbox-doc](http://www.swisscom.ch/tvbox-doc)



### **Homologation and WEEE**

The icon indicates, that the product shall not be treated as household waste. Please dispose of it professionally as electronic waste (municipal collection point or Swisscom Shop). The remote control, manufactured by Ruwido, was designed to meet the obligation of homologation and to comply with essential requirements and other relevant provisions of European Directive WEEE (Waste of Electrical and Electronic Equipment) 2012/19/EU.

### **Manufacturer**

Ruwido Austria gmbh,  
Köstendorfer Straße 8,  
5202 Neumarkt a. w.,  
**Austria**



KKD+JM (B2C-TSP-UID) 11044058 03/2021 EN

**Swisscom blue TV**  
(Swisscom Box/  
Swisscom Box 21)


# Replacing your remote control

### **Swisscom (Switzerland) Ltd.**

Postfach  
3050 Bern  
[www.swisscom.ch/tvbox-help](http://www.swisscom.ch/tvbox-help)  
0800 800 800



Remove the batteries from the **old remote control** and dispose of everything professionally.




1

Switch on your TV.




2

Insert the batteries provided in the **new remote control**.



3

**Swisscom Box:** turn off your TV-Box and turn it on again.  
**Swisscom Box 21:** unplug the power supply for the TV-Box and plug it back in.



4

Press the WPS button on the TV-Box for 3 seconds and then let go.



5

Hold your new remote control up to the TV-Box and press «ok». The LED will then flash white until the remote is connected.



6

You can now enjoy watching blue TV again.

