



BY
TIMOTHY OULTON
MICHAEL YEUNG

ASSEMBLY INSTRUCTION

TORQUE PENDANT 12CM

PARTS ENCLOSED

ITEMS	DIAGRAM	DESCRIPTION	QTY.
(A)		Junction Box (Not included) 1 50LB. MIN. FIXTURE RATED	1
(B)		Mounting Screws (Not included)	2 Sets
(C)		Screw Nut	2
(D1)		Wire Nut	3
(D2)		Terminal Box	1
(E1)		Ceiling plate	1
(E2)		Canopy	1
(E3)		Screw Nut	2
(E)		Body	1

IMPORTANT SAFETY INSTRUCTIONS:


1. Use an authorized and certified electrician for consultation and installation.
2. This fixture has been rated for 3-watt maximum non-replaceable LED lightsource.
3. To avoid the risk of fire, do not exceed the recommended wattage.
4. The ceiling must have at least the capacity of 5 times the weight of the ceiling light. For this light at least a ceiling capacity of XXXkg (XXX lb) is required.
5. The manufacturer and distributor accepts no liability for incorrect installation.
6. For indoor use only.
7. Keep away from children.

Warnings:

1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your ceiling light is fully assembled and installed.
2. All wires are connected. Do not remove the ceiling light from its packaging by pulling on the power cord, as a bad connection may result.
3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the ceiling light and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Glass & Iron
Height: 16.3 cm (6.42in)
Diameter: 12.0cm (4.72in)
Weight: 2.4 kg (5.3lbs)
Grounded / Hardwired



TO ASSEMBLE:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the ceiling light will be installed.
3. Loosen the screw nut (E3) and remove the ceiling plate (E1) from the canopy (E2).
4. Attach the ceiling plate (E1) to the ceiling with mounting screws (B).
5. Connect wires from the fixture to the ceiling wires referring to **Wire & Safety Guidelines** with wire nuts (D1) or terminal box (D2).
6. Move the canopy (E2) up to the ceiling, then fasten the Screw nut (E3).
7. Restore power to the junction box and test ceiling light fixture.

CARE INSTRUCTIONS:

1. Make sure that the power is turned off and bulb has cooled before handling.
2. Wipe clean with a dry cloth / mild soapy solution. Do not use corrosive cleaners.
3. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.
4. The light source contained in this luminaire shall only be replaced by the manufacturer or its service agent or a similar qualified person.

ENVIRONMENT:

Special waste handling may be required. Please contact your local authorities for more information.