



TIMOTHY OULTON

ASSEMBLY INSTRUCTION

REX SIDEBOARD 156X47CM

PARTS ENCLOSED

ITEMS	DIAGRAM	DESCRIPTION	QTY.
(A)		Body	1
(B)		100mm Glass rod	98+3
(C)		595mm Glass rod	97+3
(D)		Tempered Glass	1
(A1)		Bolts	10
(A2)		Diffuser Plate	1
(E)		Adjustable feet	6
(F)		Bulbs	10
(G)		Silicone Pad	16
(H)		Metal Plate	2
(I)		Bolts	16+4
(J)		PE Foam (L515*W31*H17 mm)	1
(K)		PE Foam (L515*W13*H14 mm)	1
(L)		Anti Kit Bracket	1 Pack

IMPORTANT SAFETY INSTRUCTIONS:

1. Use an authorized and certified electrician for consultation and installation.
2. This fixture has been rated for ten (10) 4watt maximum LED E14 bulbs .
3. To avoid the risk of fire, do not exceed the recommended wattage.
4. The manufacturer and distributor accepts no liability for incorrect installation.
5. For indoor use only.
6. Keep away from children.

WARNINGS:

1. Turn-off electricity supply at main circuit panel before installing. Do not connect electricity supply until your fixture is fully assembled and installed.
2. All wires are connected. Do not remove the fixture from its packaging by pulling on the power cord, as a bad connection may result.
3. To reduce the risk of fire, electrical shock, or personal injury, always turn off the fixture and allow it to cool prior to replacing light bulb. Do not touch bulb when fixture is turned on or look directly at light bulb. Keep flammable materials away from light bulb.
4. Deviation from instructions may result in a risk of fire or electric shock.

PRODUCT DESCRIPTION:

General material: Iron
 Length: 156.0cm (61.42in)
 Width: 46.5cm (18.31in)
 Height: 76.0cm (29.92in)
 Weight: 176.5kg (388.3lbs)
 Grounded / Hardwired

ASSEMBLY INSTURCTIONS:

1. Carefully remove all parts from the box and remove all plastic covering.
2. Turn OFF power to the junction box where the fixture will be installed.
3. Install the adjustable feet (E) in the bottom of the body and adjust the feet to keep the body in level if necessary.
4. Loose the bolts (A1) and take out the diffuser plate (A2) from the body (A).
5. Fasten the bulbs (F) to the lampholders.
6. Put the diffuser plate (A2) back in its place and secure it onto the body with bolts (A1).
7. Push the glass rod (B) upward into a hole in the inner layer of the frame, then insert the same rod into the corresponding hole in the opposite end. Repeat to fit the glass rod into the top layer until all the rods are installed.
8. Push the glass rod (C) toward into a hole in the top layer of the frame, then insert the same rod into the corresponding hole in the opposite end. Repeat to fit the glass rod into the top layer until all the rods are installed.
9. Cover the silicone pad (G) onto bolt head (A1), then place the tempered glass (D) on the top of the sideboard.
10. Unscrew the bolts (I) on the top of the door, take the metal place (H) away from the top of the door.
11. Insert PE foam (K) into the inner side of the glass rods (C) in the top of metal door and place the PE foam (J) cover onto the top of the glass rods (C), then put the metal place (H) back to the top of doors with bolts (I).
12. Attach the anti-bracket (L) to the wall with mounting screws.
13. Thread the strap provided through both bracket (L) and metal bar inside of the body(B) and tighten strip until snug. Do not over tighten.
14. Insert plug into socket and test fixture.

CARE INSTRUCTIONS:

1. Make sure that the power is turned off and bulb has cooled before handling.
2. Wipe clean with a dry cloth. Do not use corrosive cleaners.
3. The cable/cord of this floor lamp cannot be replaced: if the cable is damaged, do not use the lamp.

ENVIRONMENT:

Special waste handing may be required. Please contact your local authorities for more information.

