

## Cut list for porch swing bench

2x6 front and back –2 @ 57 ½ inches

2x6 ends –2 @ 21 inches (3 pocket holes at each end)

2x4 supports –6 @ 21 inches (2 pocket holes at each end)

2x4 front and back and backrest –3 @ 48 ½ inches (2 pocket holes at each end)

2x4 side rails –2 @ 27 (2 pocket holes at each end)

2x4 armrest horizontal supports –2 @ 27  
(2 pocket holes at each end, and two along the side of the board)

2x4 armrest vertical supports –2 @ 12 inches (2 pocket holes at one end)

2x4 handrail –2 @ 28 ½ inches (2 pocket holes at one end only)

2x4 headrest –1 @ 55 ½ inches

