

TROUBLESHOOTING GUIDE

Double-click
to reverse



TRY REVERSING

Reverse the plastic out of the pen and insert a new strand.



APPLY PRESSURE

Click the fast button and insert a new strand while applying pressure.



USE UNBLOCKING TOOL

Remove the nozzle while the light is blue or green. Then force through plastic from the back or the front with the unblocking tool.

Is the LED light red for more than 2 minutes?

Exit idle mode by unplugging your pen and plugging it back in or by turning your pen off and on again.



Still having trouble?



Check out the manuals
3Doodler.com/manuals



Contact us
(US) 415-619-8248

